Garage door opener (HomeLink[®])

Garage door opener (HomeLink[®])

General Safety Instructions

Pinching, crushing or knocking against the operated equipment

Risk of accidents when using or programming the garage door opener if persons or animals are within the range of movement of the equipment that is being operated.

- When using or programming the HomeLink[®] system, ensure that no persons, animals or objects are within the range of movement of the equipment that is being operated.
- Observe the safety notes for the original remote control.

Operating principle

With the HomeLink® system, up to eight remotecontrolled items (e.g. for garage doors / entry gates to your property, security systems, house lights) can be operated from the vehicle via profiles in the central display.

Observe the instructions for the original remote control.

Information

For information on the compatibility of your vehicle's HomeLink[®] system with the original hand transmitter:

- Contact your Porsche partner.
- Visit www.homelink.com or call the free HomeLink® hotline (0)0800 046 635 465 or (0) 08000 HOMELINK.

Information

Before selling your vehicle, remember to delete the garage door opener signals.

Using the garage door opener

Manually executing the taught HomeLink* profile

- Ready for operation.
- Vehicle is aligned towards the receiver and within range of the receiver (signal is transmitted in direction of travel).

1. □ ► HomeLink* S

2. Select the desired profile.

If the existing HomeLink® profiles are assigned to GPS coordinates, the profiles are filtered on the basis of the current vehicle position.

HomeLink® Automatically executing profiles

- Ready for operation.
- ✓ Vehicle is aligned towards the receiver and within range of the receiver (signal is transmitted in direction of travel).
- ✓ GPS coordinates assigned to HomeLink[®] profile.

Shortly before reaching a HomeLink® system with assigned GPS coordinates, the relevant profile is displayed automatically and proposed for execution.

Programming garage door opener

- Ready for operation.
- ✓ Vehicle is aligned towards the receiver and within range of the receiver (signal is transmitted in direction of travel).

Programming a new garage door opener

- 1. ▲ HomeLink[®] ► Teach new profile
- 2. Follow the instructions displayed.

Synchronising systems with changeable code

For systems with a rolling code, synchronisation of the HomeLink[®] system is also required. This starts automatically after teach-in. A second person makes programming easier.



Information

If you have not been able to successfully assign signals to the buttons even though you have carefully followed the instructions in this section and the operating instructions for the original remote control:

- Contact your Porsche partner.
- Make sure that the battery in the remote control for the garage door opener is new. If the battery voltage is inadequate, faults may occur in signal transmission. The system in the vehicle then learns an incorrect code, which cannot be reliably recognised.
- Check the compatibility of the vehicle's HomeLink[®] system with the original hand transmitter.

Managing learned profiles

Renaming learned profiles; adding or deleting GPS coordinates

- 1. 🎑 ► HomeLink® 🌑
- 2. Select the **we button for the respective profile**.
- $\textbf{3.} \hspace{0.1 cm} \textbf{Select the desired option.} \\$

Deleting a learned profile

- 1. 🚺 ► HomeLink* 🌑
- **2.** Swipe to drag the profile you wish to delete from the profile list.

Deleting all learned profiles

► HomeLink^{*} S ► · · · ► Delete all Home-Link^{*} profiles

A B